

COMPREHENSIVE VALIDATION PACKAGE

ATL Applications

INVENTORY SHEET

WORK ORDER # 0910022B

	Page Nos.	
	From	To
1. Work Order Cover Page & Laboratory Narrative & Table	1	3
2. Sample Results and Raw Data (Organized By Sample)	4	7
a. ATL Sample Results Form		
b. Target Compound Raw Data		
-Internal Standard Area and Retention Time Summary (If Applicable)		
-Surrogate Recovery Summary (If Applicable)		
-Chromatogram(s) and Ion Profiles (If Applicable)		
3. QC Results and Raw Data		
a. Method Blank (Results + Raw Data)	-	-
b. Surrogate Recovery Summary Form (If Applicable)	-	-
c. Internal Standard Summary Form (If Applicable)	-	-
d. Duplicate Results Summary Sheet	-	-
e. Matrix Spike/Matrix Spike Duplicate (Results + Raw Data)	-	-
f. Initial Calibration Data (Summary Sheet + Raw Data)	-	-
g. MDL Study (If Applicable)	-	-
h. Continuing Calibration Verification Data	-	-
i. Second Source LCS (Summary + Raw Data)	-	-
j. Extraction Logs	-	-
k. Instrument Run Logs/Software Verification	8	13
l. GC/MS Tune (Results + Raw Data)	-	-
4. Shipping/Receiving Documents:		
a. Login Receipt Summary Sheet	14	15
b. Chain-of-Custody Records	16	16
c. Sample Log-In Sheet	17	18
d. Misc. Shipping/Receiving Records (list individual records)		
<u>Sample Receipt Discrepancy Report</u>	-	-
5. Other Records (describe or list)		
a. <u>Manual Spectral Defense</u>	-	-
b. <u>Manual Intergrations</u>	-	-
c. <u>Manual Calculations</u>	-	-
d. <u>Canister Dilution Factors</u>	-	-
e. <u>Laboratory Corrective Action Request</u>	-	-
f. <u>CAS Number Reference</u>	19	20
g. <u>Variance Table</u>	-	-
h. <u>Canister Certification</u>	-	-
i. <u>Data Review Check Sheet</u>	21	21

Completed by:

Kara McKiernan

(Signature)

Kara McKiernan/ Document Control

(Print Name & Title)

10/21/09

(Date)

WORK ORDER #: 0910022B

Work Order Summary

CLIENT:	Mr. Taeko Minegishi Environmental Health & Engineering, Inc. 117 Fourth Avenue Needham, MA 02494	BILL TO:	Accounts Payable Environmental Health & Engineering, Inc. 117 Fourth Avenue Needham, MA 02494
PHONE:	800-825-5343	P.O. #	16512
FAX:	781-247-4305	PROJECT #	16512
DATE RECEIVED:	10/01/2009	CONTACT:	Ausha Scott
DATE COMPLETED:	10/20/2009		

<u>FRACTION #</u>	<u>NAME</u>	<u>TEST</u>
17A	101792	ATL Applications
17AA	101792 Lab Duplicate	ATL Applications
18A	101793	ATL Applications
18AA	101793 Lab Duplicate	ATL Applications
19A	101794	ATL Applications
20A	101818	ATL Applications
21A	101819	ATL Applications
22A	101820	ATL Applications
23A	101821	ATL Applications
24A	101822	ATL Applications
25A	101823	ATL Applications
26A	101909	ATL Applications
27A	101910	ATL Applications
28A	101911	ATL Applications
29A	101912	ATL Applications
30A	101913	ATL Applications
31A	101914	ATL Applications
32A	Lab Blank	ATL Applications

Continued on next page


WORK ORDER #: 0910022B

Work Order Summary

CLIENT:	Mr. Taeko Minegishi Environmental Health & Engineering, Inc. 117 Fourth Avenue Needham, MA 02494	BILL TO:	Accounts Payable Environmental Health & Engineering, Inc. 117 Fourth Avenue Needham, MA 02494
PHONE:	800-825-5343	P.O. #	16512
FAX:	781-247-4305	PROJECT #	16512
DATE RECEIVED:	10/01/2009	CONTACT:	Ausha Scott
DATE COMPLETED:	10/20/2009		

<u>FRACTION #</u>	<u>NAME</u>	<u>TEST</u>
32B	Lab Blank	ATL Applications
33A	CCV	ATL Applications

CERTIFIED BY:



Laboratory Director

DATE: 10/20/09

This report shall not be reproduced, except in full, without the written approval of Air Toxics Ltd.

180 BLUE RAVINE ROAD, SUITE B FOLSOM, CA - 95630
(916) 985-1000 . (800) 985-5955 . FAX (916) 985-1020

**LABORATORY NARRATIVE
Nitrogen Dioxide by Radiello 166
Environmental Health & Engineering, Inc.
Workorder# 0910022B**

Fifteen Radiello 166 (NO₂) samples were received on October 01, 2009. The procedure involves extraction of nitrite from reaction of NO₂ with triethanolamine. Absorbance of nitrite is then measured at 537 nm using a spectrophotometer. Results are reported in uG and uG/m³.

Sampling rate of 141 mL/min was provided by the manufacturer.

Receiving Notes

There were no receiving discrepancies.

Analytical Notes

Results were calculated based on 25 deg C without temperature correction. The actual exposure time was used to calculate sample concentrations and reporting limits.

An exposure time of 20160 minutes was used for the QC samples.

All media used for the sampling were supplied by the client. Blank subtraction was not performed on the sample results since the media used for Method Blanks may be from a different lot than the media used for the samples.

Definition of Data Qualifying Flags

Eight qualifiers may have been used on the data analysis sheets and indicate as follows:

- B - Compound present in laboratory blank greater than reporting limit.
- J - Estimated value.
- E - Exceeds instrument calibration range.
- S - Saturated peak.
- Q - Exceeds quality control limits.
- U - Compound analyzed for but not detected above the detection limit.
- M - Reported value may be biased due to apparent matrix interferences.
- N - The identification is based on presumptive evidence.

File extensions may have been used on the data analysis sheets and indicates as follows:

- a-File was requantified
- b-File was quantified by a second column and detector
- r1-File was requantified for the purpose of reissue

Sample Results and Raw Data

AIR TOXICS LTD.

ATL Application # 61 for RAD 166 (Nitrogen Dioxide)

Spectrophotometer

Field Sample I.D.	Lab Sample I.D.	Collection Date	Analysis Date	Dilution Factor	Reporting Limit (ug)	Reporting Limit (ug/m3)	Amount (ug)	Amount (ug/m3)
101792	0910022B-17A	9/29/2009	10/6/2009	1.00	0.32	0.22	2.6	1.7
101792 Lab Duplicate	0910022B-17AA	9/29/2009	10/6/2009	1.00	0.32	0.22	2.6	1.7
101793	0910022B-18A	9/29/2009	10/6/2009	1.00	0.32	0.22	1.5	1.0
101793 Lab Duplicate	0910022B-18AA	9/29/2009	10/6/2009	1.00	0.32	0.22	1.5	1.0
101794	0910022B-19A	NA	10/6/2009	1.00	0.32	0.22	ND	ND
101818	0910022B-20A	9/29/2009	10/6/2009	1.00	0.32	0.22	2.8	1.8
101819	0910022B-21A	9/29/2009	10/6/2009	1.00	0.32	0.22	1.7	1.1
101820	0910022B-22A	9/29/2009	10/6/2009	1.00	0.32	0.22	0.66	0.44
101821	0910022B-23A	9/29/2009	10/6/2009	1.00	0.32	0.22	2.1	1.4
101822	0910022B-24A	9/29/2009	10/6/2009	1.00	0.32	0.22	2.0	1.4
101823	0910022B-25A	NA	10/6/2009	1.00	0.32	0.22	ND	ND
101909	0910022B-26A	9/30/2009	10/6/2009	1.00	0.32	0.22	7.5	5.0
101910	0910022B-27A	9/30/2009	10/6/2009	1.00	0.32	0.22	7.6	5.0
101911	0910022B-28A	9/30/2009	10/6/2009	1.00	0.32	0.22	3.1	2.0
101912	0910022B-29A	9/30/2009	10/6/2009	1.00	0.32	0.22	3.6	2.4
101913	0910022B-30A	9/30/2009	10/6/2009	1.00	0.32	0.22	4.4	2.9
101914	0910022B-31A	NA	10/6/2009	1.00	0.32	0.22	ND	ND
Method Blank	0910022B-32A	NA	10/6/2009	1.00	0.32	0.22	ND	ND
Method Blank	0910022B-32B	NA	10/6/2009	1.00	0.32	0.22	ND	ND
CCV	0910022B-33A	NA	10/6/2009	1.00	0.32	0.22	%Rec 102	

COMMENTS: 1. NA=Not Applicable
2. ND=Not Detected
3. Exposure time of 20160 minutes was assumed for the QC samples.
4. Background subtraction not performed.

Dioxide Radiello Calculation Worksheet

Workorder #: 0910022B

1000ng/1ug

Sampling Rate (ug/(ppb*min))

0.141

Typically 0.96 for NO2

Sampling T (deg C)

25

Typically 25

Volume (ml)

5

Typically 5 for NO2

Date of Analysis:

10/6/2009

(Abs-Y-int)xDF

Conc(ug)x5 (ml)

Conc (ug) x 1000
Q x Duration

ppbx nmw
24.45

Corrected Q

0.141

es into account temp

LabSampleID	Client	Date of Collection	Abs	Duration (min)	DF	Conc (ug) (for 0.5ml Aliquot)	Conc (ug) in full 5 ml of sample	Conc (ppb)	Conc (ug/m3)
17A	101792	9/29/2009	0.077	20160	1.00	0.255336811	2.553368108	0.898	1.690
17AA	101792 Lab Duplicate	9/29/2009	0.078	20160	1.00	0.259949838	2.599498385	0.914	1.721
18A	101793	9/29/2009	0.055	20160	1.00	0.153850201	1.538502014	0.541	1.018
18AA	101793 Lab Duplicate	9/29/2009	0.054	20160	1.00	0.149237174	1.492371737	0.525	0.988
19A	101794	NA	0.013	20160	1.00	-0.039896962	-0.398969618	-0.140	-0.264
20A	101818	9/29/2009	0.082	20160	1.00	0.278401949	2.784019492	0.979	1.843
21A	101819	9/29/2009	0.058	20160	1.00	0.167689285	1.676892845	0.590	1.110
22A	101820	9/29/2009	0.036	20160	1.00	0.066202675	0.662026752	0.233	0.438
23A	101821	9/29/2009	0.067	20160	1.00	0.209206534	2.092065338	0.736	1.385
24A	101822	9/29/2009	0.066	20160	1.00	0.204593506	2.045935061	0.720	1.354
25A	101823	NA	0.017	20160	1.00	-0.021444851	-0.21444851	-0.075	-0.142
26A	101909	9/30/2009	0.185	20160	1.00	0.753543802	7.535438019	2.651	4.987
27A	101910	9/30/2009	0.186	20160	1.00	0.75815683	7.581568296	2.667	5.018
28A	101911	9/30/2009	0.088	20160	1.00	0.306080115	3.060801154	1.077	2.026
29A	101912	9/30/2009	0.100	20160	1.00	0.361436448	3.614364478	1.272	2.392
30A	101913	9/30/2009	0.118	20160	1.00	0.444470946	4.444709463	1.564	2.942
31A	101914	NA	0.010	20160	1.00	-0.053736045	-0.537360449	-0.189	-0.356
						-0.099866322	-0.998663218	#DIV/0!	#DIV/0!
						-0.099866322	-0.998663218	#DIV/0!	#DIV/0!
						-0.099866322	-0.998663218	#DIV/0!	#DIV/0!
						-0.099866322	-0.998663218	#DIV/0!	#DIV/0!
						-0.053736045	-0.537360449	-0.189	-0.356
						-0.049123017	-0.491230172	-0.173	-0.325
						0.665896276	6.658962757	2.343	4.407

32A	Method Blank	NA	0.010	20160	1.00	-0.053736045	-0.537360449	-0.189	-0.356
32B	Method Blank	NA	0.011	20160	1.00	-0.049123017	-0.491230172	-0.173	-0.325
33A	CCV	NA	0.166	20160	1.00	0.665896276	6.658962757	2.343	4.407

QC Duration
20160

CCV Spike Amt ug
per 0.5 ml
0.65

1000ng/1ug

Low PointDF

$\frac{RL(\mu g) \times 5 (ml)}{0.5 ml}$

$\frac{RL(\mu g) \times 1000}{Q \times Duration}$

$\frac{ppbx\ mw}{24.45}$

Calibration Data

Calibration Date
10/6/2009 Linear Regression

0.5 mL
Aliquot of Cal
STD

RL(μg) for 0.5 mL aliquot

RL (ppb)

RL ($\mu g/m^3$)

Result (μg)

Result ($\mu g/m^3$)

%Rec

ug/ml of NO2
ug of NO2
absorbance

Slope
Y-int
R2

0.216777367
0.021648758
0.998634774

0.033	0.325	0.1	0.215	2.553368108	1.68998464		0	0	0
0.033	0.325	0.1	0.215	2.599498385	1.72051665		0.065	0.0325	0.017
0.033	0.325	0.1	0.215	1.538502014	1.018280429		0.325	0.1625	0.049
0.033	0.325	0.1	0.215	1.492371737	0.98774842		1.3	0.65	0.163
0.033	0.325	0.1	0.215	ND	ND		6.5	3.25	0.764
0.033	0.325	0.1	0.215	2.784019492	1.842644688		13	6.5	1.412
0.033	0.325	0.1	0.215	1.676892845	1.109876458				
0.033	0.325	0.1	0.215	0.662026752	0.438172248				
0.033	0.325	0.1	0.215	2.092065338	1.384664544				
0.033	0.325	0.1	0.215	2.045935061	1.354132535				
0.033	0.325	0.1	0.215	ND	ND				
0.033	0.325	0.1	0.215	7.535438019	4.987441674				
0.033	0.325	0.1	0.215	7.581568296	5.017973683				
0.033	0.325	0.1	0.215	3.060801154	2.025836745				
0.033	0.325	0.1	0.215	3.614364478	2.39222086				
0.033	0.325	0.1	0.215	4.444709463	2.941797032				
0.033	0.325	0.1	0.215	ND	ND				
0.033	0.325	#DNV/01	#DNV/01	ND	#DNV/01				
0.033	0.325	#DNV/01	#DNV/01	ND	#DNV/01				
0.033	0.325	#DNV/01	#DNV/01	ND	#DNV/01				
0.033	0.325	#DNV/01	#DNV/01	ND	#DNV/01				
0.033	0.325	#DNV/01	#DNV/01	ND	#DNV/01				
0.033	0.325	0.1	0.215	ND	ND				
0.033	0.325	0.1	0.215	ND	ND	%Rec			
0.033	0.325	0.1	0.215	6.658962757	4.407333492	102			

QC Results and Raw Data

Work Order: 09100223

Date: 10/6/09

Method: Rad 166

Analyst: M. Skidmore

Wavelength: 537 nm

Standard ID	Concentration	ABS
Level 1 1858-80-E	0.065 mg/mL	0.017
Level 2 -D	0.325 mg/mL	0.049
Level 3 -C	1.3 mg/mL	0.163
Level 4 -B	6.5 mg/mL	0.764
Level 5 -A	13 mg/mL	1.412
ICV 1858-82	1.3 mg/mL	0.173

$$r = 0.9986$$

$$m = 0.2168$$

$$b = 0.0216$$

ICV % Recovery = 107

Fraction	Dilution	ABS	Sample ID	Sample Volume	Comments
17A	1.00	0.077	101792	5.0 mL	
17AA		0.078	101792		
18A		0.055	101793		
18AA		0.054	101793		
19A		0.013	101794		
20A		0.082	101818		
21A		0.058	101819		
22A		0.036	101820		
23A		0.067	101821		
24A		0.066	101822		
25A		0.017	101823		
26A		0.185	101909		
27A		0.186	101910		
28A		0.088	101911		
29A		0.100	101912		
30A		0.118	101913		
31A		0.010	101914		
Blk		0.010	N/A		Lot: 09133
Blk		0.011			
LCS		0.160			
CCV		0.166			
<div style="display: flex; justify-content: space-between;"> X MJS 10/6/09 MJS 10/7/09 </div>					

Procedure:

M. Skidmore
Signed

10/7/09
Date

Spectrophotometer Standard Preparation Log

@Air Toxics Ltd. Log Book #: 1858

Standard ID: 1858-39

Project: NEOA Solution Rad 166

Analyst: M. Skidmore

Preparation Date: 9/18/09

Expiration Date: until when solution turns brown
9/18/09

Solvent: DI H₂O

Solvent Lot #: N/A

Procedure/Comments: Dissolve 250 mg of N-(1-Naphthyl)ethylenediamine
dihydrochloride, 98% (1476-1105, located ERIA) in 250 mL
DI H₂O.

MJS
9/18/09

Spectrophotometer Standard Preparation Log

@Air Toxics Ltd. Log Book #: 1858

Standard ID: 1858-79

Project: Sulfanilamide Solution Rad 166

Analyst: M. Skidmore

Preparation Date: 10/6/09

Expiration Date: 10/6/09

Solvent: HCl/H₂O

Solvent Lot #: HCl: 49198

Procedure/Comments: Dissolve 5.0 g of Sulfanilamide, 99%
(1476-1104) (located in PERIA) in 50 mL of
Concentrated HCl and dilute to 500 mL with
D.I. H₂O.

Spectrophotometer Standard Preparation Log

@Air Toxics Ltd. Log Book #: 1858

Standard ID: 1858-80
Project: Calibration Solutions Rad 166
Analyst: M. Skidmore
Preparation Date: 10/6/09
Expiration Date: 10/6/09

Solvent: D.I. H₂O
Solvent Lot #: N/A

Procedure/Comments:


Dissolve 5 mg of Sodium Nitrate, 97% (located in ER2D) in 250 mL of D.I. H₂O to yield 13 µg/mL or 13 mg/L. From this solution, dilute to make:

6.5 µg/mL	1.3 µg/mL	0.325 µg/mL	0.065 µg/mL
(315:630)	(130:650)	(150:600)	(100:500)

Each of these uses serial dilution from the previous solution.

To each of these calibration levels, add 5 mL of sulfanilamide solution, cap tightly, stir and wait 5 minutes. Then add 1 mL of NEDA solution, stir and wait 10 minutes. Measure the absorbance at 537 nm.

MJS
10/06/09



Spectrophotometer Standard Preparation Log

@Air Toxics Ltd. Log Book #: 1858

Standard ID: 1858-82
Project: ICV Rad 166
Analyst: ly
Preparation Date: 10/6/09
Expiration Date: 10/6/09

Solvent: D.I. H₂O
Solvent Lot #: N/A

Procedure/Comments: _____

Dissolve 5 mg of Sodium Nitrate, 97% (located in ER2D) in 250 mL of D.I. H₂O to yield 13 µg/mL or 13 mg/L. 100 µL of this solution was diluted with D.I. H₂O to a volume of 1.0 mL. 0.5 mL of this solution was added to a cuvette. 5 mL of sulfanilamide solution was added to the cuvette. The solution was parafilmmed and stirred and allowed to stand for 5 minutes. 1.0 mL of NEDA solution was then added and was stirred and allowed to sit for 10 minutes. The absorbance was then read at 537 nm.

MSS 10/6/09

ly
Signed

10/6/09
Date

[Signature]
Reviewed

10/7/09
Date

10/6/09
Rev. 8/97

Shipping/ Receiving Documents

**180 Blue Ravine Road, Suite B
Folsom, CA 95630**

**Phone (916) 985-1000 FAX (916) 985-1020
Hours 8:00 A.M. to 6:00 P.M. Pacific**

COMPANY: Environmental Health & Engineering, Inc.
ATTENTION: Mr. Taeko Minegishi
FAX #: 781-247-4305
FROM: Sample Receiving
Workorder #: 0910022B
of pages (Including Cover): 4

10/21/2009

Thank you for selecting Air Toxics Ltd. We have received your samples and have found no discrepancies. In order to expedite analysis and reporting, please review the attached information for accuracy. Corrections can be faxed to **Ausha Scott at 916-985-1020.** ATL will proceed with the analysis as specified on the Chain of Custody and Sample Login page.

9/30/09

FROM: Environmental Health and Engineering, Inc.
117 Fourth Avenue
Needham, MA 02494-2725

0910022

TO: Air Toxics

Please send invoices to ATTN: Accounts Payable
Please send reports to ATTN: Data Coordinator

In all correspondence regarding this matter, please refer to EH&E Project # 16512

The cost of this analysis will be covered by EH&E Purchase Order # 16512

For EH & E Data Coordinator - URGENT DATA X

SAMPLE ID	SAMPLE TYPE	ANALYTICAL METHOD/NUMBER	Start	OTHER: Time/Date/Vol.	Stop
17A 101792	Air/Passive	NO ₂ SO ₂ HF Analysis	9/15/09	9/29/09	
18A 101793					
19A 101794					
20A 101818			9/15/09	9/29/09	
21A 101819					
22A 101820					
23A 101821					
24A 101822					
25A 101823					
26A 101909			9/16/09	9/30/09	
27A 101910					
28A 101911					
29A 101912					
30A 101913					
31A 101914					

Special Instructions:

☒ Standard turn around time

☐ Rush by _____ date/time


☐ Fax results 781-247-4305

☐ RETURN SAMPLES

☒ Additional report recipient

☒ Electronic transfer - datacoordinator@ehinc.com

M. Fragala @ ehinc.com



Each signatory please return one copy of this form to the above address

Relinquished by: [Signature] of Environmental Health & Engineering, Inc. Date: 9/30/09

Received by: [Signature] of (company name) ATI Date: 10/1/09

Relinquished by: _____ of (company name) _____ Date: _____

Received by: _____ of (company name) _____ Date: _____

Relinquished by: _____ of (company name) _____ Date: _____

Received by: _____ of (company name) _____ Date: _____

Lab Data

Received by: _____ of Environmental Health & Engineering, Inc. Date: _____

Page 2 of 2

SAMPLE RECEIPT SUMMARY

WORKORDER 0910022B

Client

Mr. Taeko Minegishi
 Environmental Health &
 Engineering, Inc.
 117 Fourth Avenue
 Needham, MA 02494

Phone

800-825-5343

Fax

781-247-4305

Date Promised: 10/12/09 11:59 pm

Date Completed: 10/20/09

Date Received: 10/1/09

PO#: 16512

Project#: 16512

Sales Rep: TL

Total \$: \$ 675.00

Logged By: MW

<u>Fraction</u>	<u>Sample #</u>	<u>Analysis</u>	<u>Collected</u>	<u>Amount\$</u>
17A	101792	ATL Applications	9/29/2009	\$40.00
17AA	101792 Lab Duplicate	ATL Applications	9/29/2009	\$0.00
18A	101793	ATL Applications	9/29/2009	\$40.00
18AA	101793 Lab Duplicate	ATL Applications	9/29/2009	\$0.00
19A	101794	ATL Applications	NA	\$40.00
20A	101818	ATL Applications	9/29/2009	\$40.00
21A	101819	ATL Applications	9/29/2009	\$40.00
22A	101820	ATL Applications	9/29/2009	\$40.00
23A	101821	ATL Applications	9/29/2009	\$40.00
24A	101822	ATL Applications	9/29/2009	\$40.00
25A	101823	ATL Applications	NA	\$40.00
26A	101909	ATL Applications	9/30/2009	\$40.00
27A	101910	ATL Applications	9/30/2009	\$40.00
28A	101911	ATL Applications	9/30/2009	\$40.00
29A	101912	ATL Applications	9/30/2009	\$40.00
30A	101913	ATL Applications	9/30/2009	\$40.00
31A	101914	ATL Applications	NA	\$40.00
32A	Lab Blank	ATL Applications	NA	\$0.00
32B	Lab Blank	ATL Applications	NA	\$0.00
33A	CCV	ATL Applications	NA	\$0.00

Note: Samples received after 3 P.M. PST are considered to be received on the following work day.
 Atlas Project Name/Profile#: CPSC Indoor Air Monitoring/13297

BILL TO: Accounts Payable
 Environmental Health & Engineering, Inc.
 117 Fourth Avenue
 Needham, MA 02494

Analysis Code: Other GC

TERMS:

Reporting Method: ATL Application #61 NO2-Radiello 166

180 BLUE RAVINE ROAD, SUITE B FOLSOM, CA - 95630
 (916) 985-1000 . (800) 985-5955 . FAX (916) 985-1020

SAMPLE RECEIPT SUMMARY Continued

Client

Phone

Date Promised:

Date Completed:

Date Received:

Fax

PO#:

Project#:

Sales Rep:

Total \$: \$ 675.00

Logged By: MW

<u>Fraction</u>	<u>Sample #</u>	<u>Analysis</u>	<u>Collected</u>	<u>Amount\$</u>
Misc. Charges eCVP (15) @ \$5.00 each.				\$75.00

Note: Samples received after 3 P.M. PST are considered to be received on the following work day.
Atlas Project Name/Profile#: CPSC Indoor Air Monitoring/13297

BILL TO: Accounts Payable
Environmental Health & Engineering, Inc.
117 Fourth Avenue
Needham, MA 02494

Analysis Code: Other GC

TERMS:

Reporting Method: ATL Application #61 NO2-Radiello 166

180 BLUE RAVINE ROAD, SUITE B FOLSOM, CA - 95630
(916) 985-1000 . (800) 985-5955 . FAX (916) 985-1020

Other Records

Method : ATL Application #61 NO2-Radiello 166

CAS Number	Compound	Rpt. Limit (ug)
10102-44-0	Nitrogen Dioxide	1.0

DATA REVIEW CHECKLIST

Work Order #:

0910022B

A₁ A₂ R T M Q

- ☐ ☐ ☒ ☐ ☒ ☐ Analysis/Reporting vs. Project Profile/SOP requirements checked (i.e. 100% Dups, J-Flag to MDL, etc)
☐ ☐ ☒ ☐ ☒ ☐ The final report has the correct reporting list, special units, and header info.
☐ ☐ ☐ ☐ ☒ ☐ Lab Narrative is correct (proper method & description/Receiving & Analytical notes correct)
☐ ☐ ☒ ☐ ☒ ☐ Sample Discrepancy Report (SDR) is completed

☐ ☐ ☒ ☐ ☐ ☐ Corrective Action issued - # _____
☐ ☐ ☐ ☐ ☒ ☐ Unusual circumstances have been documented in the notes section below

LUMEN validation report present and initialed

CIRCLE (YES / NO)

- ☐ ☐ ☒ ☐ ☒ ☐ Lab Blank, CCV, LCS and DUP met QC criteria
☐ ☐ ☒ ☐ ☒ ☐ Hold time is met for all samples
☐ ☐ ☒ ☐ ☒ ☐ Appropriate data qualifier flags are applied
☐ ☐ ☒ ☐ ☒ ☐ Manual integrations for samples and QC are properly documented
☐ ☐ ☒ ☐ ☐ ☐ Samples analyzed within the project or method specific clock
☐ ☐ ☒ ☐ ☐ ☐ Retention times have been verified
☐ ☐ ☒ ☐ ☐ ☐ Appropriate ICAL(s) included
☐ ☐ ☐ ☒ ☐ ☐ At least one result per sample is verified against the target quant sheets/raw data

☐ ☐ ☒ ☐ ☐ ☐ Dilution factor correctly calculated (sample load volume, syringe and bag dilutions, can pressurization(s))
☐ ☐ ☒ ☐ ☐ ☐ Correct amount of sample analyzed (i.e. sample not over-diluted)
☐ ☐ ☒ ☐ ☐ ☐ Spectra verified - documentation of spectral defense included (Section 5A of eCVP pkg)

☐ ☐ ☒ ☐ ☐ ☐ TICs resemble reference spectra
☐ ☐ ☒ ☐ ☐ ☐ TICs between duplicate samples are consistent
☐ ☐ ☒ ☐ ☒ ☐ Checked samples for trends (i.e. Influent vs. Effluent, Field Dups, Field/Trip Blank, etc.)
☐ ☐ ☒ ☐ ☐ ☐ Data for multiple analyses of sample(s) has been evaluated for comparability of results

☐ ☐ ☒ ☐ ☒ ☐ Special units for all samples in the final report are correctly calculated
☐ ☐ ☒ ☐ ☒ ☐ Manually entered results checked (i.e. TPH/NMOC)

☐ ☐ ☒ ☐ ☐ ☐ Chain of Custody verified for any special comments (i.e. different compounds/RLs, action levels)
☐ ☐ ☒ ☐ ☐ ☐ Chain of Custody scanned correctly
☐ ☐ ☒ ☐ ☐ ☐ Verify sample id's vs. chain of custody
☐ ☐ ☒ ☐ ☐ ☐ Date MDL(s) performed per instrument(s) 9/21/09

☐ ☐ ☒ ☐ ☐ ☐ Samples pressurized w/ appropriate gas (N₂ or He) ☐ Other (i.e. Tedlar bag, cartridge, sorbent)
☐ ☐ ☒ ☐ ☐ ☐ Final pressure consistent with canister size (6L vs. 1L)
☐ ☐ ☒ ☐ ☐ ☐ Verify receipt pressures

☐ ☐ ☒ ☐ ☐ ☐ Verify canister ID #'s
☐ ☐ ☐ ☒ ☐ ☐ Final invoice amount correct (adjusted for TAT, Penalties, Re-issue Charges etc.)

☐ ☐ ☐ ☒ ☐ ☐ MDL date(s) present for all instruments utilized
☐ ☐ ☒ ☐ ☐ ☐ Client LUMEN report reviewed for accuracy and completeness

Notes: (to include: noting samples with QA/QC problems, Blanks with positive hits, narratives, etc.)

A/R:

M/Q:

A₁/A₂

(Analytical Review/Date)

R/T

(Reporting Review/Date)

M

(Management Review/Date)

Q

(QA Review/Date)

A₁:

R:

M: 10/24/09

A₂:

T:

Note (1): Please check all the appropriate boxes. Indicate "NA" for any statement that does not apply.

Rev. 02/20/09

Note (2): Management reviewer and reporting reviewer must be separate individuals.